


CORnell®

User Manual



**Rice
Cooker**

**CRC-JP108SS
CRC-JP188SS**

SAFETY PRECAUTION

1. Read all instructions carefully. Keep this User Manual for future reference.
2. Always unplug the Appliance from the mains electrical outlet before cleaning it or when not in use.
3. Always attach the power cord to the appliance BEFORE plugging it to the mains electrical outlet. To disconnect the power cord from the appliance, switch it off first before removing the plug from the main electrical outlet.
4. Never leave the appliance unattended while it is still connected to the power supply.
5. Do not operate the appliance with damaged power cord set or plug. Any repairs should always be done by an experienced technician or by an authorized service center.
6. Always place the appliance on a flat sturdy surface. When moving it, always be aware not to touch on hot surface or any hot liquid it may contain.
7. Do not immerse appliance or electrical parts into water or any other types of liquid.
8. Use of accessories or equipment not supplied by the manufacturer may result in damages or malfunction on the appliance or injuries to the user.
9. Do not use the appliance for other than its intended use.
10. Do not use in the outdoors.


11. This appliance is not intended for use by people (including children) who are physically or mentally impaired or lack the experience and knowledge unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

12. This appliance is for HOUSEHOLD USE ONLY.


CAUTION FOR RICE COOKER

- 1) When washing the rice, always use another container and not the inner pot, because over some time the inner pot will be damaged if used in this manner.
- 2) The Rice Cooker will not function when the inner pot is not placed inside the cooker.
- 3) Always keep the base of the inner pot and the heater surface clean and dry. Foreign object located between inner pot and heater surface will cause the Rice Cooker to malfunction.
- 4) Do not use force to turn on/off the appliance. If it is difficult to engage the switch, check for incorrect placement of the inner pot or if there are foreign objects on the heating plate.
- 5) It is recommended not to use the Keep Warm function for more than 4 hours. Whilst the Rice Cooker will not be damaged, but the rice will become discolored and a burn smell may be detected.
- 6) Correct measurement of one cup of rice is when the rice grains are level with the top of the cup. Use only the cup supplied together with the appliance as all measurement showed below is referring to this cup. Provided cup's capacity is 180ml.


PARTS IDENTIFICATION



CONTROL PANEL



ACCESSORIES



SPECIFICATIONS

Model	CRC-JP108SS	CRC-JP188SS
Rated Voltage	220-240V~	220-240V~
Rated Power	500W	700W
Frequency	50/60Hz	50/60Hz

- *10 Years Warranty on the stainless steel material and manufacturing defect for the BUFFALO Stainless Steel Rice Pot.*
- *Cornell is not responsible on the warranty for the coating material (external part) and damage caused by user handling and methods of usage.*

HOW TO OPERATE RICE COOKER

Condensation Collector

How to detach: Put your hand at the gap of the upper lid and the condensation collector and pull outwards.


How to attach: Align the shaft on the condensation collector with the steam outlet vent located on the upper lid. Press down firmly only when they are aligned.

NEVER REMOVE THE CONDENSATION COLLECTOR WHILST THE APPLIANCE IS BEING USED.

How to clean the Condensation Collector

How to open: Hold the top part of the Condensation Collector and twist the lower portion anti-clockwise. The two parts will separate to allow for cleaning. Clean at least once or twice a week.

How to attach: Ensure all the two parts are dry. Seat the lower portion into groves provided and turn clockwise till fully attached. Place the Condensation Collector back to the top lid.



HOW TO COOK RICE

1. Measure the amount of rice needed with the measuring cup provided.
2. Put the washed rice into the inner pot and add water. In general 1 cup of water is needed for 1 cup of rice. However, it is recommend to use the water level (RICE) provided on the inner pot.

Water Level for Cooking Rice

Uncooked Rice Cups	CRC-JP108SS Water Level	CRC-JP188SS Water Level
1 Cup	1	1
2 Cups	2	2
3 Cups	3	3
4 Cups	4	4
5 Cups	5	5
6 Cups	-	6
7 Cups	-	7
8 Cups	-	8
9 Cups	-	9
10 Cups	-	10

Note: *The table above is meant as a guide only. Ratio between rice and water change according to the type of rice used and user preference.*

3. Press the function selector to “COOK” position, and then press the power switch. The COOK indicator light will be on.
4. When the rice is cooked, the POWER switch will pop up and the KEEP WARM indicator light will be on. The Rice Cooker will be automatically switched over to the KEEP WARM function.
5. Stir up the rice as quickly as possible after cooking finished (within 30 minutes) as it may become sticky and lumpy.
6. For best results, it is recommended that the Keep Warm function be allowed to continue for about 15 minutes before opening the lid or starting to scoop out the rice.

HOW TO COOK PORRIDGE

1. Measure the amount of rice needed with measuring cup provided.
2. Put the washed rice into the inner pot and add water. It is recommend to use the water level (Porridge) provided on the inner pot.

Water Level for Cooking Porridge

Uncooked Rice Cups	CRC-JP108SS Water Level	CRC-JP188SS Water Level
0.5 Cup	0.5	0.5
1.0 Cup	1.0	1.0
1.5 Cups	-	1.5

Note: *The table above is meant as a guide only. Ratio between rice and water change according to the type of rice used and user preference.*

3. Soak the rice in the water for more than 30 minutes to 1 hour.
4. Press the function selector to “PORRIDGE” position, and then press the power switch. The PORRIDGE indicator light will be on.
5. Before use, be certain to wipe away any grains of rice or water droplets clinging to the outer surface of the inner container or temperature sensor.
6. When cooking is completed, stir up carefully before serve as porridge.
7. CAUTION: Do not keep warm porridge.
8. NOTE: Porridge cooking requires user to turn off the porridge function manually upon reaching the desired result.

TIPS FOR COOKING PORRIDGE

1. Do not open the lid within 1 hour while the porridge is cooking.
2. Open the lid when the time is beyond 1 hour.
3. The normal porridge cooking time is about 1 hour. However you may adjust the time according to personal taste requirement.

CAUTION: The water and uncooked rice must not exceed the MAX water level.

HINTS TO COOKING GOOD RICE

1. Use provided cup to measure rice cup level by topping up until its rim. Provided cup's capacity is 180 ml.
2. Be careful of water amount. Please note the water amount always depend on quantity of rice. Different kinds of rice produce different localities, hard or soft.
3. Summer soak for 30 minutes, winter soak for 1 hour or more. If rice contains water, it can become un-transparent.
4. Use the rice spoon given to stir the rice evenly after cooked, to let some extra water vaporize.
5. Correct way of keeping warm. Small amount of rice should be kept in the centre of the pot. If placing cold rice and rice spoon in the pot for keep warm, it will produce unpleasant odor.

Soaking Time Chart For Reference

Kind of Rice	Soaking Time	Scale : Rice : Water
Hard rice	15 – 30min	1 cup : 1 – 1.2 level
5 cereal rice	1hr 30min	1 cup : 1.3 – 1.8 level
Brown rice	1 hr	1 cup : 1.3 Level
Fragrance rice	20min	1 cup : 1.2 Level
Red rice	1 hr	1 cup : 1.5 – 1.8 Level
Small rice	15min	1 cup : 0.8 – 1 Level

TROUBLE-SHOOTING

Check again \ Symptom	During Cooking		
	Spread out	A lot of steam escape from rim	Drip off
Water, rice amount correct or not	■	■	
Bottom of inner pot even or not			■
Pot outer side heater, thermostat, any rice attached	■	■	■
Wash rice properly or not	■		
Switch off or unplug during cooking			■
Top cover close properly or not	■	■	■
Whether there is rice grain between cover and body	■	■	

Symptom Check again	Cooked Rice				
	Too hard	Some rice uncooked	Too soft	Bottom burn rice	Long time to cook
Water, rice amount correct or not	■	■	■	■	■
Bottom of inner pot even or not	■	■	■	■	■
Pot outer side heater, thermostat, any rice attached	■	■	■	■	■
Open cover during keep warm	■	■			
Stir the rice after cooked	■	■	■		
Wash rice properly or not				■	
Switch off or unplug during cooking					■
Top cover check properly or not	■	■			
Whether there is rice grain between cover and body	■	■			

Symptom Check again	Keep Warm		
	Become hard	Yellowish	Smelly
Stir the rice after cooked		■	■
Wash rice properly or not	■	■	■
Switch off or unplug during cooking	■	■	■
Keep warm more than 12 hours	■	■	■
Top cover check properly or not	■	■	■
Whether spoon is inside the pot		■	■
Whether add cool rice in keep warm	■	■	■
Whether there is rice grain between cover and body	■	■	■

CARE AND CLEANING

Before commencing to clean the Rice Cooker, ensure that the Mains power supply is switched OFF and the power cord is removed from the appliance. Wait until the appliance is at room temperature before commencing to clean it.

1. DO NOT use a metal scoop to scoop out rice or congee as it may damage the stainless steel surface on the inner pot. Fill with hot water into inner pot for a while and then wash it with soapy water using a sponge. After that, wipe it thoroughly with dry cloth.
2. DO NOT use abrasive sponge, scouring pads, or stiff brush to clean your Rice Cooker. The Inner Pot, Steam Tray, Rice Spoon and Soup Ladle may be cleaned with mild soapy water using a sponge of soft cloth.
3. Occasionally wipe the exterior surface with a mild and damp cloth. Never use a corrosive cleaner.

4. Occasionally check that there are no foreign objects in the inner part of the Rice Cooker, on the heater or the centre thermostat. Remove them if found. Wipe surface with a damp cloth.
5. Use damp cloth to remove cooked rice or any remaining rice stick to the heating plate. Smooth out and polish the spot to ensure good contact between the heating plate and the bottom of inner pot.
6. Clean the Condensation Collector frequently and pour away any water found inside. Wash under a running tap and dry it before putting back onto the Rice Cooker. **Clean it after every usage.**
7. The inner part of the Lid should be cleaned as frequently as possible (**recommended once a week**) with a damp cloth. Pay special attention to the joints between the seal and the Lid. Remove remaining food particles left there. Wipe the inner surface of the outer lid with a damp cloth. **Clean it after every usage.**

Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



Marketed by:

CORNELL SALES & SERVICE SDN BHD (604369-P)

Lot 11B, Jalan 223, Section 51A,
46100 Petaling Jaya,
Selangor Darul Ehsan, Malaysia.

InfoLine: 1-800-881-770
www.cornellappliances.com